

DATA SHEET – Rocking Chair ROK-FB01



Thanks to its secure one-piece design, the ROK-FB01 rocking chair meets the demanding requirements of healthcare facilities and high-risk environments. Easy to clean, compatible with hospital disinfection protocols, and 100% recyclable, it also provides excellent impact resistance and comes with a lifetime warranty for optimal durability.

Thanks to its one-piece construction with no removable components and enhanced stability, the ROK-FB01 rocking chair meets the demanding requirements of high-risk environments and sensory spaces. Easy to clean, compatible with hospital disinfection protocols, and 100% recyclable, it also offers an optional ballast system and comes with a lifetime warranty for optimal durability.

■ Height	37,4 po
■ Width	27,2 po
■ Depth	38,6 po
■ Weight	25 kg
■ Options	Floor fixing – Ballast up to 50 kg



*Lifetime warranty



Standards and compliance

- **ISO 7170** – Furniture strength and durability
- **REACH (EC No. 1907/2006)** – Regulation on chemicals and chemical substances
- **ISO 846:2019** – Resistance to fungal and bacterial growth
- **UL 94 HB** – Flammability testing of plastic materials
- Manufactured under **MASE certification**
- **ISO 9001** certification process underway



Click here
to learn more



Cleaning Protocol

- High-Density Polyethylene (HDPE) structure
- Non-porous, 100% waterproof and recyclable surface
- Compatible with hospital disinfection protocols
- Resistant to common disinfectants, alcohols, and hospital detergents
- Pre-cleaning: remove visible soiling, then rinse thoroughly with clean water
- Routine cleaning with a neutral or mildly alkaline detergent
- Apply using a microfiber cloth or a soft non-abrasive sponge
- Thorough rinsing after cleaning is recommended
- Compatible with:
 - Diluted bleach solution 0.1–0.5%
 - Ethyl or isopropyl alcohol ≤ 70%
 - Hydrogen peroxide ≤ 30%
 - EN 14885-certified hospital disinfectants
- Recommended contact time: 5 to 15 minutes depending on the product used
- Rinsing is mandatory after the use of chlorine-based or peroxide-based products
- Air dry or wipe dry with a clean, lint-free cloth
- Do not use chlorinated solvents, hydrocarbons, abrasive products, or concentrated acids
- Daily cleaning recommended in healthcare environments
- Disinfection after each patient in psychiatric or secure care environments
- Regular visual inspection of the furniture's integrity after cleaning and maintenance procedures recommended